



Instructions for applying window film

Tools that you will need

Razor scraper
Olfa style snapping blade knife
Squeegee
Paper towels
Stiff plastic “5-way” tools or plastic trowel
Tape measure
Spray bottle
Baby shampoo

1. Pre-cut film to ½” larger than opening to be covered.
2. Mix about 1 litre of filtered or distilled water with 2 drops of baby shampoo in spray bottle.
3. Spray surface of glass opening with soapy mix and clean with razor scraper.
4. Spray again and squeegee then wipe perimeter and frame with paper towel.
5. Repeat steps 3 and 4 until you are satisfied that the window is very clean.
6. (It is best if you have a helper to remove the liner from the film). Lightly spray both sides of the film with mix. Spray glass surface thoroughly. Peel liner from film and spray sticky side of film as you expose it.
7. If your windows are square and the film is cut straight you may try and position the film in the upper left or right corner. If not, overlap all edges of the glass with the film.
8. Spray surface of the film and gently squeegee water from center of work and push out to edges of film.
9. Trim excess of film using as straight edge as a guide.
10. Cover the 5-way tool or a stiff plastic edge with paper towel and continue to push water to the outer edge of the film.
11. Continue pushing out the excess water with the plastic edge until you are satisfied that you cannot remove any more water.
12. If you discover some small water bubbles after installation, don't worry! In time these should evaporate away without a trace.